

Distributed by:



**Corrosion
Control
Equipment
and
Supplies**

Houston Office:
248 McCarty Dr.
Houston, TX 77029-1195
(713) 672-8251
Fax (713) 672-6636

1-800-CLEMTEX
www.clemtex.com
clemtex@clemtex.com

Dallas Branch:

4770 Gretna
Dallas, TX 75207
(214) 631-0584
Fax (214) 631-5824
1-800-BLAST 97

Corpus Christi Branch:

4750 Westway
Corpus Christi, TX 78408
(361) 882-8282
Fax (361) 882-6029

PosiTest DFT

Coating Thickness Gage

Instruction Manual ver. 2.0



Combo: measures on all metals.

The letter “F” (ferrous, e.g. steel) or “N” (non-ferrous, e.g. aluminum) is displayed with each reading depending on the substrate. Gage automatically recognizes the substrate.

Ferrous: measures on steel only.

The letter “F” is always displayed.

Operation

Automatic power up when probe is depressed.

Power down after 30 seconds of no activity.

Place flat on surface. Hold steady. When measurement is obtained, new reading flashes and gage beeps. Lift gage.

Measurement Units

Press and **Hold** both buttons to convert from mils to microns or vice versa.

Zeroing

Press and release both buttons simultaneously. The display blinks “0”. Measure the uncoated part. Zeroing provides best coating thickness accuracy.

Reset

Press and release both buttons 3 times to restore the factory zero setting. Handy when an uncoated part is not available for zeroing.

Flip Display

Press either button to rotate display.

Shims

Shims provide a quick operational check. Also used for protection on tacky, rough or hot surfaces.

AAA Alkaline Battery

Replace when  stays on LCD.

Range: 0-40 mils 0-1000 μm

Accuracy: $\pm(0.1 \text{ mils} + 3\%) \pm(2\mu\text{m} + 3\%)$

For more information, visit
www.defelsko.com/positestdft.htm
©DeFelsko Corporation USA 2007