CLEMTEX



Corrosion Control Equipment and Supplies

Houston Office 248 McCarty Dr. P.O. Box 15214 Houston TX, 77220-5214 (713) 672-8251 Fax (713) 672-6336 Email clemtex@clemtex.com

1-800-CLEMTEX www.clemtex.com

Corpus Christi Branch 4750 Westway P.O. Box 5036 Corpus Christi, TX 78465 (361) 882-8282 Fax (361) 882-6029 **Dallas Branch** 4770 Gretna Dallas, TX 75207 (214) 631-0584 Fax (214) 631-5824 1-800-BLAST 97

Clemtex Anchor Pattern Standards

The CAPS (Clemtex Anchor Pattern Standards) are designed for the purpose of a quick field inspection of a blast cleaned surface to determine anchor pattern depth within $\frac{1}{2}$ Mil.

The anchor pattern is all-important to protective coatings in that it provides excellent coating adhesion. It is important that the anchor pattern be uniform over its entire surface. This is accomplished using a clean, well-graded or sized abrasive.

The chart included will aid in obtaining the proper abrasive size specified.

It should be remembered that abrasive sizes vary and a close inspection of size tolerance (approx. 10%) should be maintained, especially where abrasives are reclaimed and re-used. Reclaimed abrasives should be angular and not rounded and free from oil, grease, iron oxide, etc.



